



This manual covers the following models:


TT-N-631W

Base Module

Up to 1 heat, 1 cool conventional

Up to 2 heat, 1 cool heat pump

Non-programmable



Congratulations on purchasing your new TopTech thermostat. This thermostat was designed to the highest reliability and ease of use standards. Thank you for choosing TopTech.



Caution:
Equipment damage hazard
Do not operate the cooling system if the outdoor temperature is below 50° F (10° C) to prevent possible compressor damage.

Table of Contents	Page
Thermostat Quick Reference	2
Thermostat Operation	3
Contact Us	4
Warranty Registration	4

Need Help?

For assistance with this product please visit <http://www.toptechparts.com>.


For technical support call 1-888-776-1427 during normal business hours (Mon-Fri 9 AM - 6 PM Eastern).

For general customer support call our Customer Care Center toll-free at 1-866-239-4440.

Una versión española de este manual puede ser descargada en www.toptechparts.com


THERMOSTAT QUICK REFERENCE

Getting to know your thermostat



- ② Fan Switch
- ③ System Switch
- ④ Set-point Buttons

① LCD




Important:

The low battery indicator is displayed when the AA battery power is low. If the user fails to replace the battery within 21 days, the thermostat display will only show the low battery indicator as a final warning before the thermostat becomes inoperable.


Battery Installation

Battery installation is optional if thermostat is hardwired (R and C terminal connected to 24v power).




Insert 2 AA Alkaline batteries (included).

Easy to use controls



Caution:

When the battery icon  appears replace your AA batteries immediately. Failure to do so may result in your heating & cooling system becoming inoperable.

① LCD Display:

See page 2 for details about this display read out.



② Fan Switch:

AUTO will cycle the fan on only when the heating or cooling system is on. Select **LOW** or **HIGH** for the fan to run continuously at the selected speed.

③ System Switch:

Selects the operation mode of your HVAC system. Selecting **HEAT** turns on the heat mode. Selecting **COOL** turns on the air conditioning mode. Selecting **OFF** turns both heating and cooling off.

④ Temperature Setpoint Buttons:

Press the  or  buttons to select the desired room temperature.

A Note About Two-Speed Fan:

When the fan switch is set to **AUTO** and the system is in **HEAT** or **COOL**, the thermostat will switch from **LOW** fan to **HIGH** fan when the ambient temperature is 2x swing away from setpoint. The thermostat will switch back to **LOW** fan at 1x swing away from setpoint.

CONTACT US AND WARRANTY INFORMATION

Contact Us Information

TopTech by Pro1
1111 S. Glenstone
Suite 2-100
Springfield, MO 65804

For General Customer Support Call Toll-free: 1-866-239-4440

For Technical Support Call Toll-free: 1-888-776-1427

Toll Number (Outside the USA): 330-821-3600

Web: <http://www.toptechparts.com>

Hours of Operation: Monday - Friday 9 AM - 6 PM Eastern

Warranty Registration:

Your new TopTech thermostat has a 5 year limited warranty. You must register your warranty within 60 days of installation. You can register your new thermostat in 2 ways.

① Go to www.toptechparts.com, and fill out a short registration form online.

- or -

② Complete the form below and mail it to the address shown.

TopTech Warranty Registration:

Name: _____

Address: _____

City: _____

State: _____

Zip: _____

Thermostat Model: TT-N-631W

Date Installed: _____

Complete form and mail to:

TopTech by Pro1
1111 S. Glenstone
Suite 2-100
Springfield, MO 65804